

USER GUIDE

REMOTE CONTROL



Untuk versi bahasa Indonesia
silahkan unduh pada website,
www.getaqila.com/download

AQILA
Rumah Lebih Aman, Lebih Pintar™

Remote Control

The compact remote control,
easy to use, easy to carry.

Designed to be easily placed on a key chain, wallet, pocket or in your car sun visor. This remote-control is an alternative device other than Aqila Smart App that can be used to operate the alarm system by change the alarm mode between Stay Arm, Away Arm, Disarm or also make an emergency call.



LED Indicator:

LED blinked:
Transmitting
signal to Aqila
Securehub™

Low LED light:
Indicates
low battery,
replace battery
immediately.

Specification:

Power Supply: DC 3V (1pc CR 2032 button cell battery)

Transmission: $\leq 6\text{mA}$

Transmission Distance: $\leq 80\text{m}$ (in Open Area)

Transmission Frequency: 433MHz FHSS Frequency Hopping

Product Material: ABS Plastic

Working Temperature: $-10^{\circ}\text{C} - 55^{\circ}\text{C}$

Humidity: Up to 80% (no condensation)

Dimensions (LxWxH): 48 x 71 x 18mm

Button Guide:



**Away
Arm**

Press the Away Arm button (locked padlock icon) to activate Away Arm Mode the on the alarm system.

The LED light on the left will blink 1 time.

Use Away Arm mode when there is no one inside your house, this mode will activate all sensors. When alarm triggered, Aqila Securehub™ will send notification to App / SMS / Phone call (depends on the setting).



Disarm

Press the Disarm button (unlocked padlock icon) to disarm the alarm system.

The LED light on the right will blink 1 time.

Use Disarmed Mode to deactivate the alarm system when you do not need any protection, for example on the mid-day when you have everybody inside the house. In this mode, only sensors that are set to 24-hour zone can triggering alarm.

This Disarm mode also can be used to turn off the alarm sound.



Stay Arm

Press the Stay Arm button (house icon) to activate Stay Arm Mode the on the alarm system.

The LED light on the left will blink 1 time.

Use Stay Arm Mode when the house is occupied, for example at night when everyone is sleeping. In this mode, sensors that are in Normal Zone will activated, while sensors that are set in the Stay Zone will be deactivated, this allows family member to move freely inside the house without triggering the alarm.



Silent Mode

Press the Stay Arm button 1 time, then press Away Arm or Disarm button within 3 seconds to enter the Stay Arm or Disarm mode in Silent Mode.



SOS

Emergency Call

In case of emergency, press the SOS button to trigger alarm.

Both LED light will blink 1 time.

System will be switched to emergency mode, activate siren and send you notifications.

